

Applying TrackIt™ Clothing Labels with an EzPress™ or PopUpPress™

1. Apply TrackIt Clothing Labels only on clean, dry fabric.
2. Set your EzPress™ or PopUpPress™ temperature to 370° Fahrenheit.
3. Set your EzPress™ or PopUpPress™ timer to 7 seconds.
4. Wait for the Press to heat to 370° Fahrenheit.
5. Apply your first label to a scrap of cloth.
6. Let the label cool to room temperature. Then try to peel it off of the fabric. Try as hard as you can. If you can get even the tiniest corner off of the fabric, the label is not applied properly. Call toll free 877.906.1818. If the label is stuck permanently to the fabric and you can not get it loose; your Press is set properly.

Applying TrackIt™ Eyeglass Labels with heat gun or hair dryer

1. The white tubing in the TrackIt Eyeglass Cartridge shrinks to ¼ of its original diameter when heated to 180° Fahrenheit, but it does not shrink in length.
2. Select the proper diameter tubing for the eyeglasses. (Use the smallest diameter tubing that will fit over the ear piece. Medium fits most popular eyeglasses. Small fits wire frame eyeglasses and large fits "Horn Rim" eyeglasses.
3. Print the TrackIt™ Eyeglass Label in your LabelAll™ printer.
4. Squeeze the end of the tube until it opens, then slip the tube over the earpiece. Position it close to the glasses.
5. Shrink the tube until it is tight against the earpiece using a heat gun or a hairdryer.

Applying TrackIt™ Rugged Labels to any smooth surface.

1. Verify that the smooth object you plan to label is clean and dry.
2. Print your label in the LabelAll™ printer.
3. Turn the label over and slit the backing with the EzSlitter™. Slit the backing across the narrow width of the label. The EzSlitter™ slits the backing but does not slit the printed label material.
4. Bend the label print side to print side at the slit and the backing material will start to lift up. Grab the ends and peel the backing material off.
5. Apply the label to your object; then, rub the surface with a cloth pressing the label firmly onto the surface of the object.
6. When applied in the above manner, TrackIt™ Rugged Labels are dishwasher proof, car wash proof, and pressure washer proof. They can be used indoors or outdoors in any weather.



Start Printing & Applying
Labels Quickly

with your

LabelAll3™

Revised 2/05/07

EzProducts International Inc
4686 W Main St Wauchula FL 33873

For questions or to order supplies, please call **toll free 877.906.1818**

863.735.0813

toll free: 877.906.1818

fax: 863.735.0328

www.EzProductsInc.com

Installing the Batteries

Included with your LabelAll printer are 6 AA batteries.

Turn the LabelAll3 printer upside down and remove the small lid to the battery compartment.

Insert two batteries in each of the three slots. Make sure that you observe the polarity symbol on the bottom of the slots and on the batteries.

Replace the lid and turn the LabelAll3 right side up.

You are ready to begin printing labels.

Using the optional AC Adaptor

Plug the optional AC Adaptor into a standard wall AC outlet and insert the small plug on the end of the wire into the AC Adaptor Jack on the left side of the rear of the LabelAll3 printer. The AC Adaptor Jack is labeled "11V 1.6A"

Installing a Label Cartridge

1. Press the **Silver Button** in the center of the printer above the keyboard to open the **Cartridge Lid**. Insert the label cartridge into the compartment.
2. Insure that the label material which is protruding out of the left side of the cartridge protrudes out of the slot in the left side of the printer.
3. Close the Cartridge Lid.

Printing a 1 Line Label

1. Make sure that there is a **Label Cartridge** installed in the printer.
2. Press the blue **On/ Off Button** located in the lower left corner of the keyboard to turn the **LabelAll3** power on.
3. Type your name and press Return.
4. Press the large light blue **Print Key**. Your label will feed out of the left side of the **LabelAll** printer and it will be cut the proper length.

Printing a Two Line Label

1. Type your name and press **Return**.
2. Type your phone number and press **Return**.
3. Press the **Print Key**.

Centering Your Text on the Label

1. Type your one or two line label as indicated above.
2. Press the light blue **Style Key** located in the upper right side of the keyboard.
3. Press the **up** or **down** arrow keys to select **Layout**. Press the **Return Key**.
4. Press the **up** or **down** arrow keys to select **Center** on the menu. Press the **Return Key**.
5. Press the **down** arrow key to select **End** on the menu. Press the **Return Key**.
6. Press the **up** or **down** arrow to select **Label** on the menu. Press the **Return Key**.

Making Your Label Larger or Smaller

You can make your label larger or smaller by making the text to be printed on the label larger or smaller.

1. Type a 1 or 2 line label as indicated above.
2. Press the light blue **Mode Key** in the upper right corner of the keyboard.
3. Press the **up** or **down** arrow key to select **Exp./Red**. Then press the **Return Key**.
4. Press the **up** or **down** arrow key to select **Expand, Normal, Reduce, Small1 or Small2**. Then press the **Return Key**.
5. Press the **down** arrow key to select **End** then press the **Return Key**.
6. Press the **up** or **down** arrow key to select **Label** then press the **Return Key**.
7. Print your label by pressing the **Print Key**.

Printing Several Identical Labels

1. Press the light blue **Rpt./Enl. Key** located near the Silver Button.
2. Press the **Return Key** to select Repeat fro the menu.
3. Press the **up** or **down** arrow keys to select the quantity then press the **Return Key**.
4. Press the **up** or **down** arrow key to select **Execute** and press the **Return Key**.

Resetting the LabelAll3 to the Factory Settings

1. Press and hold down the yellow **Shift Key** and press the light blue **BS Key** located in the upper right corner of the keyboard.
2. The word **Delete** will appear on the screen. Use the **up** or **down arrow** keys to select **All** then press **Return**.